

Oracle SBC integration with Genesys Cloud BYOC and Microsoft Teams Direct Routing

Technical Application Note

ORACLE
COMMUNICATIONS

Disclaimer

The following is intended to outline our general product direction. It is intended for information purposes only and may not be incorporated into any contract. It is not a commitment to deliver any material, code, or functionality, and should not be relied upon in making purchasing decisions. The development, release, and timing of any features or functionality described for Oracle's products remains at the sole discretion of Oracle.

Revision History

As a best practice always follow the latest Application note available on the Oracle TechNet Website.
https://www.oracle.com/technical-resources/documentation/acme-packet.html

Version	Description of Changes	Date Revision Completed
1.0	Oracle SBC integration with Genesys BYOC Cloud and Microsoft Teams	07 July 2021
1.1	Oracle Public IP Addresses masked	18 Nov 2021
1.2	Removed sip-all FQDN Added New Access Control	12 Jan 2022
1.3	Added New Section BYOC Cloud Configuration Assistant	27 Jan 2022
1.4	Removed MAuth TLS and updated Cipher List Changed Genesys PureCloud to Genesys BYOC Cloud Added Root CA list and EKU considerations for Microsoft Teams	19 Feb 2026

Table of Contents

1. Intended Audience

This document is intended for use by Oracle Systems Engineers, third party Systems Integrators, Oracle Enterprise customers and partners and end users of the Oracle Enterprise Session Border Controller (SBC). It

is assumed that the reader is familiar with basic operations of the Oracle Enterprise Session Border Controller platform along with Genesys BYOC Cloud and Microsoft Teams Direct Routing.

2. Document Overview

This Oracle technical application note outlines how to configure the Oracle SBC to interwork between Genesys BYOC Cloud and Microsoft Teams. The Application note focuses on the steps required to create a SIP connection between Genesys Cloud BYOC, Oracle SBC and Microsoft Teams through which voice communication is possible between BYOC Cloud and MS Teams Direct Routing Users.

It should be noted that the SBC configuration provided in this guide focuses strictly on the Genesys BYOC Cloud and Microsoft Teams related parameters. Microsoft Teams Direct Routing is the Microsoft's BYOC so the calls To and From MS Teams to BYOC Cloud are terminated via a carrier SIP Trunk. The steps required to configure the Carrier Trunk are specific to individual customers and are not covered in this guide. Please contact your Oracle representative with any questions pertaining to this topic.

You can follow our Application Note - https://www.oracle.com/a/otn/docs/oracle-sbc-with-genesys-cloud-cx-and-twillio-sip-trunkv0.3.pdf as a reference to configure the Twilio SIP Trunk with Oracle SBC.

Related documentation can be found below –

2.1. Microsoft Teams

Microsoft Phone System Direct Routing allows connection of a supported customer-provided Session Border Controller (SBC) to a Microsoft Phone System. Direct Routing enables using virtually any PSTN trunk with Microsoft Phone System and configuring interoperability between customer-owned telephony equipment, such as a third-party private branch exchange (PBX), analog devices, and Microsoft Phone System.

https://docs.microsoft.com/en-us/microsoftteams/direct-routing-configure

https://docs.microsoft.com/en-us/microsoftteams/direct-routing-sbc-multiple-tenants#create-a-trunk-and-provision-users

https://www.oracle.com/a/otn/docs/vzbwithsbcmsftteams-mb.pdf

https://docs.microsoft.com/en-us/microsoftteams/direct-routing-plan#public-trusted-certificate-for-the-sbc

2.2. Genesys BYOC Cloud

The Genesys BYOC Cloud solution provides flexibility and interoperability to the BYOC Cloud suite of voice services by allowing you to define SIP trunks between the BYOC Cloud AWS-based Edge and Media Tier and third-party carriers over the public Internet.

https://help.myBYOC Cloud .com/articles/about-byoc-cloud/

3. Requirements

- Oracle Enterprise Session Border Controller (hereafter Oracle SBC) running 8.4.0 version. The solution contained within this document has been tested using Oracle Communication SBC release **cz840p5a**.
- Genesys Pure Cloud BYOC (Cloud or Premise)
- Microsoft Teams Direct Routing

✓ *Tenant -Microsoft O365 Tenant with customer domain registered.*

✓ *License -Microsoft Phone System • Microsoft Teams + Skype for Business Plan 2 if included in Licensing Sku*

✓ *Oracle SBC FQDN and Public Trusted Certificates for Direct Routing.*

Follow Below Links for detailed MS Teams Direct Routing Requirements

https://docs.microsoft.com/en-us/microsoftteams/direct-routing-plan
https://www.oracle.com/a/otn/docs/final_version_nonmedia_bypass-10-05-2021.pdf

Note: Microsoft Teams Direct Routing Supports multiple configuration models. Please choose appropriate model depending upon your specific requirement. Detailed information about Microsoft Teams Direct Models with Oracle SBC can be found under Microsoft Teams Subsection -

https://www.oracle.com/technical-resources/documentation/acme-packet.html

3.3. Architecture



Above figure illustrates the connection between Genesys BYOC Cloud, Oracle SBC and Microsoft Teams Direct Routing. Both BYOC Cloud and Microsoft Teams are connected to the Oracle SBC Public FQDN /IP

Oracle SBC which is certified with Microsoft Teams Direct Routing is used to steer the signaling, media to, and From the BYOC Cloud to Microsoft Teams and vice versa. The Scenario represents a use-case where SBC is

hosted in On Premise Network however the Oracle SBC can also be hosted in Public Cloud depending upon the use-case requirement.

The configuration, validation and troubleshooting are the focus of this document and will be described in three phases

Phase 1 – Configuring Genesys BYOC Cloud

Phase 2 – Configuring Microsoft Teams Direct Routing

Phase 3 – Configuring Oracle Session Border Controller.

Note IP Addresses, FQDN and configuration names and details given in this document are used for reference purposes only. These same details cannot be used in customer configurations. End users of this document can use the configuration details according to their network requirements. There are some public facing IPs (externally routable IPs) that we use for our testing are masked in this document for security reasons. You can configure any publicly routable IPs for these sections as per specific network architecture needs.

4. Configure Genesys BYOC Cloud

The steps outlined below is the minimum required configuration to pair your SBC with Genesys BYOC Cloud. work with your Genesys representative to implement the correct configuration for your specific environment.

Note: The document only includes the steps required on Genesys BYOC Cloud to communicate with Oracle SBC as an External Trunk. Additional configuration may apply which may not be covered in this document. Please work with your Genesys representative for the most optimal Pure Cloud configuration as per your requirement.

To implement Genesys Cloud BYOC with Oracle SBC, you use the Telephony Admin UI to create SIP trunks between the BYOC Cloud Media Tier resources in AWS and the Oracle SBC. Oracle SBC connects to the BYOC Cloud to Microsoft Teams over the Direct Routing based infrastructure.

The Oracle Enterprise SBC will act as an intermediary between Microsoft Teams and Genesys BYOC Cloud. The SBC is configured to broker calls as a back-to-back user agent (B2BUA) between the two systems. The Carrier DIDs are assigned to users on BYOC Cloud System and Microsoft Teams who can originate and accept the calls. These calls traverse through Oracle SBC with which we can implement several security and additional features as per our requirement.

For the purpose of this Application note, the connection between Oracle SBC and Genesys BYOC Cloud is set over a Secure TLS 1.2 and SRTP based connection.

4.1 External Trunk Configuration

A trunk connects a communication service to a BYOC Cloud telephony connection option and facilitates point-to-point communication. We will configure Oracle Enterprise SBC as an external Trunk on the BYOC Cloud Portal. Detailed steps to configure the external trunk can be found here-

https://help.myBYOC Cloud .com/articles/create-a-byoc-cloud-trunk/

To configure the external Trunk, Navigate to

Admin> Telephony>Trunks> External Trunks > **Create New**.

4.1.1 Create a new External Trunk

Type: BYOC Carrier Trunk

Protocol: TLS (TCP and UDP are also available)

4.1.2 Set Inbound SIP Termination Identifier

Inbound SIP Termination Identifier – is the DNS Name we will configure on the Oracle SBC and will be used to route calls towards BYOC Cloud . Here a vanity FQDN **byoc-voxai.byoc.mypurecloud.com** is generated with the inbound sip termination identifier as byoc-voxai. This FQDN resolves to the following IP Addresses of the BYOC Cloud AWS US Data Centers.

Inbound SIP Termination Identifier: byoc-voxai
Ex: INVITE sip:+xxxxxxxxxxx@byoc-voxai.byoc.mypurecloud.com
Protocol: TLS
Genesys Reference - https://help.myBYOC Cloud .com/articles/tls-trunk-transport-protocol-specification/

 # Genesys Cloud IP List

IP Addresses	Load Balancer DNS Names
52.203.12.137	lb01.voice.use1.pure.cloud
54.82.241.192	lb02.voice.use1.pure.cloud
54.82.241.68	lb03.voice.use1.pure.cloud
54.82.188.43	lb04.voice.use1.pure.cloud



4.1.3 Set Outbound SIP Servers or Proxies

Outbound SIP Termination FQDN is the Public FQDN of the Oracle SBC.

4.1.4 Set Calling Address

The Calling Address is the default number used as an outbound ANI when a call is placed on the Trunk. In case a user has assigned the optionally DID that number can be used in place of the default number.



4.1.5 Set SIP Access Control

Whitelist the Oracle SBC IP addresses under the SIP Access Control. (DNS name not supported)

4.1.6 Enable E.164 format

By default, calls sent out of trunks do not include the "+" prefix, to enable E.164 number formatting disable omitting the "+". The settings can be found in the external trunk configuration, under the Identity Section. This setting is available for both inbound and outbound calls.

4.2 Site Configuration.

A site is a list of rules for routing calls. Objects such as phones associated with a site share the same rules. When a user makes a call from a phone, the system looks up the site and the call type in order to route the call to the best outbound phone line, or endpoint. Phones that are associated with a site are usually located in the same general area and have the same general purpose. A site is used to link trunk with Pure Cloud Edge(s).

Detailed steps to configure the Site can be found here-

https://help.myBYOC Cloud .com/articles/create-site-genesys-cloud-voice/

4.2.1 Create a New Site

To Create a site, Navigate to **Admin>Telephony>Sites> Create New**.

Type a name into the **Site Name** box.

From the **Location** list, select a location for your site.

From the **Time Zone** list, select your time zone.

Under **Media Model**, select **Cloud**.

Click **Create Site**.



4.2.2 Number Plans & Classifications

BYOC Cloud provides a set of default number plans that work for most users. We can modify this numbering Plan as per our specific need. We have created a new Numbering Plan “BYOC” where we will define the Numbers that take the route associated with this trunk. You can assign specific numbers, a range or numbers or even use Regex for routing.



4.2.3 Configure outbound route

The Outbound route binds the numbering plans with the trunk. The classification created in numbering plan should be assigned to the Outbound Route associated with the external trunk.



4.2.4 Phone configuration

Below is an example of a WebRTC Phone configuration which will be used for calling purpose and is assigned to the Users. The WebRTC Phone is assigned to the Oracle BYOC Site.



4.2.5 Simulate call

Genesys BYOC Cloud provides a neat feature to test and validate the routing of calls for troubleshooting purpose. Below is an example for a call to BYOC type number classification on this Site. Success indicates a successful routing response.



4.3 DID Assignment

4.3.1 Create DID Range

To create a New DID Range or Number Navigate to **Admin**.> **Telephony** > **DID Numbers**> **Create Range.** Provide the DID range and Service Provider name and Click Save



4.3.2 Assign DID to User.

On users' profile field, one of the DID can be assigned to BYOC Cloud User as Other Number. The Oracle SBC is configured to send calls from external world to this DID number which will terminate to the user on BYOC Cloud .

4.4. Architect flow for inbound welcome prompt

Below is an example for an Architect Flow for inbound Voice Prompt which will be used for inbound calls from Microsoft Teams to Genesys BYOC Cloud via Oracle SBC.



5. Configure Microsoft Teams Direct Routing

The steps outlined below is the minimum required configuration to pair your SBC with Microsoft Teams Direct Routing Interface. **This is to be used as an example only, and we highly recommend you work with your Microsoft Account representative to implement the correct configuration for your specific environment.**

5.1. Access Teams Admin center

The first step is to access the Teams Admin Center with administrator admin credentials:



5.2. Configure Online PSTN Gateway

Configuration Path: Voice/Direct Routing/SBC



Click Add, Type US and Canada, next, click Apply



5.4. Configure Online Voice Routes

Configuration Path: Voice/Direct Routing/Voice Routes



5.5. Configure Online Voice Routing Policy

Configuration Path: Voice/Voice Routing Policies



5.6. Assign Voice Routing Policy to Users

Configuration Path: Users/Select the “User”/Policies

Next to Voice Routing Policy, Click Edit and Assign. In this example, we have selected Teamsuser1:



For More Information about configuring Microsoft Teams to Connect to your SBC, Setting up users, or configuration voice routing, please refer to the Related Documentation Section of this guide.

With this, Microsoft Teams Direct Routing config is complete.

6. Configuring the SBC

This chapter provides systematic guidance on how to configure Oracle SBC for Genesys BYOC Cloud and Microsoft Teams.

6.1. Validated Oracle SBC version

Oracle conducted tests with Oracle SBC 8.4 software – this software with the configuration listed below can run on any of the following products:

- AP 1100
- AP 3900
- AP 4600
- AP 6300
- AP 6350
- VME

6.2 New SBC configuration

If the customer is looking to setup a new SBC from scratch, please follow the section below.

6.2.1 Establishing a serial connection to the SBC

Note: The below method is applicable to the SBCs running on Hardware Platforms. For VME and Cloud SBCs the method of configuration will be different to as shown below. Follow the appropriate documentation or contact your Oracle representative for details about how to configure the VME and Cloud SBC platforms.

Connect one end of a straight-through Ethernet cable to the front console port (which is active by default) on the SBC and the other end to console adapter that ships with the SBC, connect the console adapter (a DB-9 adapter) to the DB-9 port on a workstation, running a terminal emulator application such as Putty. Start the terminal emulation application using the following settings:

- Baud Rate=115200
- Data Bits=8
- Parity=None
- Stop Bits=1
- Flow Control=None

Power on the SBC and confirm that you see the following output from the boot-up sequence



Enter the default password to log in to the SBC. Note that the default SBC password is “acme” and the default super user password is “packet”.

Both passwords must be changed according to the rules shown below.

```
Password:
%
% Only alphabetic (upper or lower case), numeric and punctuation
% characters are allowed in the password.
% Password must be 8 - 64 characters,
% and have 3 of the 4 following character classes :
%      - lower case alpha
%      - upper case alpha
%      - numerals
%      - punctuation
%
Enter New Password:
Confirm New Password:

Password is acceptable.
```

Now set the management IP of the SBC by setting the IP address in bootparam.

To access bootparam. Navigate to Configure terminal->bootparam.

```
NN4600-139# conf t
NN4600-139(configure)# bootparam

'.' = clear field;  '-' = go to previous field;  q = quit

Boot File               : /boot/nnSCZ840p3B.bz
IP Address              : 10.138.194.139
VLAN                    : 0
Netmask                 : 255.255.255.192
Gateway                 : 10.138.194.129
IPv6 Address            :
IPv6 Gateway            :
Host IP                 :
FTP username            : vxftp
FTP password            : vxftp
Flags                   :
Target Name             : NN4600-139
Console Device          : COM1
Console Baudrate        : 115200
Other                   :

NOTE: These changed parameters will not go into effect until reboot.
Also, be aware that some boot parameters may also be changed through
PHY and Network Interface Configurations.


        ERROR   : space in /boot      (Percent Free: 40)

NN4600-139(configure)#
```

Note: There is no management IP configured by default.

Setup product type to Enterprise Session Border Controller as shown below.

To configure product type, type in setup product in the terminal

```
NN4600-139#
NN4600-139# setup product

----------------------------------------------------------------
WARNING:
Alteration of product alone or in conjunction with entitlement
changes will not be complete until system reboot
```

Enable the features for the ESBC using the setup entitlements command as shown

Save the changes and reboot the SBC.

```
Entitlements for Enterprise Session Border Controller
Last Modified: Never
------------------------------------------------------------------
 1 : Session Capacity                        : 0
 2 :   Advanced                              :
 3 : Admin Security                          :
 4 : Data Integrity (FIPS 140-2)             :
 5 : Transcode Codec AMR Capacity            : 0
 6 : Transcode Codec AMRWB Capacity          : 0
 7 : Transcode Codec EVRC Capacity           : 0
 8 : Transcode Codec EVRCB Capacity          : 0
 9 : Transcode Codec EVS Capacity            : 0
 10: Transcode Codec OPUS Capacity           : 0
 11: Transcode Codec SILK Capacity           : 0

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 1

  Session Capacity (0-128000)                : 500

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 3

************************************************************
CAUTION: Enabling this feature activates enhanced security
functions. Once saved, security cannot be reverted without
resetting the system back to factory default state.
************************************************************
  Admin Security (enabled/disabled)          :

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 5

  Transcode Codec AMR Capacity (0-102375)    : 50

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 2

    Advanced (enabled/disabled)              : enabled

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 10

  Transcode Codec OPUS Capacity (0-102375)   : 50

Enter 1 - 11 to modify, d' to display, 's' to save, 'q' to exit. [s]: 11

  Transcode Codec SILK Capacity (0-102375)   : 50
```

The SBC comes up after reboot and is now ready for configuration.

Navigate to **configure terminal->system->http-server-config**.

Enable the http-server-config to access the SBC using Web GUI. Save and activate the config.

```
NN4600-139(http-server)#
NN4600-139(http-server)# show
http-server
        name                                webServerInstance
        state                               enabled
        realm
        ip-address
        http-state                          enabled
        http-port                           80
        https-state                         disabled
        https-port                          443
        http-interface-list                 REST,GUI
        http-file-upload-size               0
        tls-profile
        auth-profile
        last-modified-by                    @
        last-modified-date                  2021-01-25 00:16:28

NN4600-139(http-server)#
```

6.2.2 Configure SBC using Web GUI

In this app note, we configure SBC using the WebGUI.

The Web GUI can be accessed through the URL http://<SBC_MGMT_IP>.



The username and password are the same as that of CLI.



Navigate to Configuration as shown below, to configure the SBC



Kindly refer to the GUI User Guide given below for more information.

https://docs.oracle.com/en/industries/communications/enterprise-session-border-controller/8.4.0/webgui/esbc_scz840_webgui.pdf

The expert mode is used for configuration.

Tip: To make this configuration simpler, one can directly search the element to be configured, from the Objects tab available.

6.3. Configure system-config

Navigate to system->system-config



Please enter the default gateway value in the system config page.



For VME, transcoding cores are required. Please refer the documentation here for more information

https://docs.oracle.com/en/industries/communications/enterprise-session-border-controller/8.4.0/releasenotes/esbc_scz840_releasenotes.pdf

The above step is needed only if any transcoding is used in the configuration.
If there is no transcoding involved, then the above step is not needed.

6.4. Configure Physical Interface values

To configure physical Interface values, Navigate to System->phy-interface.

Here we have configured, Network-interface M00 for Microsoft Teams and M10 for BYOC Cloud.

Parameter Name	**Microsoft Teams (M00)**	**BYOC Cloud (M10)**
Slot	0	1
Port	0	0
Operation Mode	Media	Media

Configure M00 interface as below.



Configure M10 interface as below -



6.5. Configure Network Interface values

To configure network-interface, Navigate to system->Network-Interface. Configure interface

The table below lists the parameters, to be configured for both the interfaces.

Note: The provided network IP addresses are given for example purpose only. In the real-world scenario We cannot use same networks on two network-interfaces hence make sure you use a different IP range for each Network-interface.

In this Setup we are using Google Public DNS to resolve the DNS names to IP Addresses.

Parameter Name	Microsoft Teams Network Interface	PureCloud Network interface
Name	M00	M10
Host Name	customers.telechat.o-test06161977.com	solutionslab.cgbubedford.com
IP address	[redacted]	[redacted]
Netmask	255.255.255.192	255.255.255.192
Gateway	[redacted]	[redacted]
dns-ip-primary	8.8.8.8	8.8.8.8
dns-ip-backup1	8.8.8.4	8.8.8.4

Configure network interface M00 as below



Similarly, configure network interface M10 as below



6.6. Enable media manager

Media-manager handles the media stack required for SIP sessions on the SBC. Enable the media manager option as below.

In addition to the above config, please set the max and min untrusted signaling values to one.
Navigate to Media-Manager->Media-Manager





6.7. Configure Realms

Navigate to realm-config under media-manager and configure a realm as shown below
The name of the Realm can be any relevant name according to the user convenience.

Use the following table as a configuration example for the three realms used in this configuration:

Config Parameter	Teams Side	GenesysCloud Realm
Identifier	Teams	GenesysCloud
Network Interface	M00	M10
Mm in realm	☑	☑
Teams-FQDN	Telechat.o-test06161977.com	
Teams fqdn in uri	☑	
Sdp inactive only	☑	
Media Sec policy	sdesPolicy	sdespolicy
RTCP mux	☑	
ice profile	ice	
Codec policy	addCN	
RTCP policy	rtcpGen	
Access Control Trust Level	High	High

6.7.1 Realm for Microsoft Teams –


Configuration
View Configuration
media-manager
codec-policy
media-manager
media-policy
realm-config
steering-pool
security
authentication-profile
certificate-record
tls-global
tls-profile
session-router
system
Modify Realm Config
Identifier
Teams
Description
Realm Facing Teams Direct Routing
Addr Prefix
0.0.0.0
Network Interfaces
M00:0.4
Media Realm List
Mm In Realm
enable
Mm In Network
enable
Mm Same Ip
enable
QoS Enable
enable
Max Bandwidth
0
(Range: 0..999999999)
Max Priority Bandwidth
0
(Range: 0..999999999)
Parent Realm


Configuration
View Configuration
media-manager
codec-policy
media-manager
media-policy
realm-config
steering-pool
security
authentication-profile
Modify Realm Config
Media Policy
Media Sec Policy
sdesPolicy
RTCP Mux
enable
Ice Profile
ice
Teams Fqdn
Teams Fqdn In Uri
enable
SDP Inactive Only
enable





6.7.2 Realm for Genesys BYOC Cloud





For more information on Access Control Trust Level, please refer to SBC Security guide link given below:

https://docs.oracle.com/en/industries/communications/session-border-controller/8.4.0/security/sbc_scz840_security.pdf

6.8. Security Configuration

6.8.1 Microsoft Teams

Microsoft Teams Direct Routing only allows TLS connections from SBC's for SIP traffic, and SRTP for media traffic. It requires a certificate signed by Certificate Authorities (CAs) that are part of the **Microsoft Trusted Root Certificate Program**. A list of currently supported Certificate Authrities can be found at:

Public trusted certificate for the SBC

6.8.1.1 Certificate Records

"Certificate-records" are configuration elements on Oracle SBC which capture information for a TLS certificate such as common-name, key-size, key-usage etc.

This section walks you through how to configure certificate records, create a certificate signing request, and import the necessary certificates into the SBC's configuration.
GUI Path: security/certificate-record

ACLI Path: config t→security→certificate-record

For the purposes of this application note, we'll create multiple certificate records. They are as follows:

- SBC Certificate (end-entity certificate)
- GoDaddy Root Cert (Root CA used to sign the SBC's end entity certificate)
- Microsoft Root Certificate Authorities (Microsoft Presents the SBC a certficate signed by one of these authorites)

Note: The GoDaddy RootCA is only part of this example, as that is the Authority we used to sign our SBC certificate. You would replace this with the root and/or intermediate certificates used to sign the CSR generated from your SBC.

6.8.1.2 SBC End Entity Certificate

The SBC's end entity certificate is the certificate the SBC presents to Microsoft to secure the connection. The only requirements when configuring this certificate is the common name must contain the SBC's FQDN and the **extended key usage list** must contain **serverAuth**. Including **clientAuth** is optional for now as Microsoft Teams Direct Routing currently permits the use of SBC client certificates even if the Client Authentication EKU is not included.

However, Microsoft has indicated that in the future, all SBC client certificates will be required to include the Client Auth EKU. When this enforcement goes into effect, a list of publicly trusted certificate authorities (CAs) that can issue such certificates will be published.

It's important to note that public CAs may stop including the Client Authentication EKU in certificates due to updated industry requirements and CA policies. You should check with your CA to determine when they plan to stop including the Client Authentication EKU by default, so you can plan accordingly.

For more information, please refer to:

https://learn.microsoft.com/en-us/microsoftteams/direct-routing-whats-new#update-on-upcoming-certificate-changes-updated-december-12-2025

and

https://www.oracle.com/a/otn/docs/microsoft-teams-ca-changes-and-eku-considerations.pdf

In this example our common name will be **telechat.o-test06161977.com.** You must also give it a name and we have included **clientAuth** to the **extended key usage list**.

For now, mutual TLS connections between your Oracle SBC and Microsoft Teams will continue to be established, even if the root CA removes or no longer supports the clientAuth EKU. Looking ahead, including the clientAuth EKU in your SBC's end entity certificate will be important to maintain compatibility and avoid future issues with Microsoft Teams Direct Routing. When submitting your CSR for signing, work with your CA to make sure the required EKU is maintained during the signing process.

If you generate a CSR using a certificate record that includes both serverAuth and clientAuth EKUs, but the CA removes the clientAuth EKU when signing the certificate, you can still import the resulting certificate into the SBC without any errors. The SBC will accept and present the certificate even if the clientAuth EKU is not included after signing.

All other fields are optional, and can remain at default values.

To Configure the certificate record:

Click Add, and use the following example to configure the SBC certificate



- Click OK at the bottom

Next, using this same procedure, configure certificate records for the Root CA certificate

6.8.1.3 Root CA and Intermediate Certificates

Go Daddy Root

The following, GoDaddyRoot, is the root CA certificate used to sign the SBC's end entity certificate. As mentioned above, your root CA and/or intermediate certificate may differ. This is for example purposes only.

Config Parameter	GoDaddy Root
Common Name	Go Daddy Class2 Root CA
Key Size	2048
Key-Usage-List	digitalSignature keyEncipherment
Extended Key Usage List	serverAuth

Key algor	rsa
Digest-algor	Sha256

Microsoft Root Certificate Authorities

The DNS name of the Microsoft Teams Direct Routing interface is sip.pstnhub.microsoft.com. Microsoft presents a certificate to the SBC which is signed by one of the CA's listed in the table below. To trust this certificate, your SBC must have all the certificate listed below as a trusted CA certificate.

Download each certificate from the official source using the links provided below:

Certificate Authority	Download Link
DigiCert Global Root CA	DigiCert Global Root CA
DigiCert Global Root G2	DigiCert Global Root G2
DigiCert Global Root G3	DigiCert Global Root G3
DigiCert TLS ECC P384 Root G5	DigiCert TLS ECC P384 Root G5
DigiCert TLS RSA 4096 Root G5	DigiCert TLS RSA 4096 Root G5
Microsoft ECC Root Certificate Authority 2017	Microsoft ECC Root Certificate Authority 2017
Microsoft RSA Root Certificate Authority 2017	Microsoft RSA Root Certificate Authority 2017

The certificates listed in the table above can also be found at:

https://learn.microsoft.com/en-us/azure/security/fundamentals/azure-ca-details?tabs=root-and-subordinate-cas-list

Please use the following table as a configuration reference: Modify the table according to the certificates in your environment.



At this point, before generating a certificate signing request, or importing any of the Root CA certs, we must **save and activate** the configuration of the SBC.



6.8.1.4 Generate Certificate Signing Request

Now that the SBC's certificate has been configured, create a certificate signing request for the SBC's end entity only. **This is not required for any of the Root CA or intermidiate certificates that have been created**.

On the certificate record page in the Oracle SBC GUI, select the SBC's end entity certificate that was created above, and click the "generate" tab at the top:



Copy/paste the text that gets printed on the screen as shown above and upload to your CA server for signature.
Also note, **another save and activate is required** before you can import the certificates to each certificate record created above.

Once you have received the signed certificate back from your signing authority, we can now import all certificates to the SBC configuration.

6.8.1.5 Import Certificates to SBC

Once certificate signing request has been completed – import the signed certificate to the SBC.

Please note – all certificates including root and intermediate certificates are required to be imported to the SBC.
Once all certificates have been imported, issue a third **save/activate** from the WebGUI to complete the configuration of certificates on the Oracle SBC.





- Once pasted in the text box, select Import at the bottom, then **save and activate** your configuration.

Repeat these steps to import all the root and intermediate CA certificates into the SBC:

6.8.2 Genesys BYOC Cloud

Genesys BYOC Cloud supports TLS connections from SBC's for SIP traffic, and SRTP for media traffic. It requires a certificate signed by one of the trusted Certificate Authorities.

6.8.2.1 Configuring Certificates

This section describes how to configure the SBC for TLS with Genesys BYOC Cloud. It requires a certificate signed by one of the trusted Certificate Authorities.

"Certificate-records" are configuration elements on Oracle SBC which captures information for a TLS certificate such as common-name, key-size, key-usage etc.

This section walks you through how to configure certificate records, create a certificate signing request, and import the necessary certificates into the SBC's configuration.
GUI Path: security->certificate-record
ACLI Path: config t->security->certificate-record

For the purposes of this application note, we'll create certificate records as below.

- SBC Certificates (end-entity certificate)
- DigiCertEVRootCA (Genesys BYOC Cloud)

- DigiCert Global Root G2(Genesys BYOC Cloud)
- DigiCert Global Root G3(Genesys BYOC Cloud)

Supported CA for Genesys BYOC Cloud BYOC

Genesys BYOC Cloud signs the BYOC Cloud endpoints with X.509 certificates issued by DigiCert, a public Certificate Authority. The customer endpoints must trust the BYOC Cloud endpoints. Genesys Cloud signs the BYOC Cloud endpoints with X.509 certificates issued by DigiCert, a public Certificate Authority. More specifically, the root certificate authority that signs the BYOC Cloud endpoints is separated by region and uses certificates authorized by either DigiCert High Assurance EV Root CA or DigiCert Global Root G2/DigiCert Global Root G3. You can download the appropriate root public key certificate for your region from DigiCert.

https://help.myBYOC Cloud.com/articles/tls-trunk-transport-protocol-specification/

https://help.genesys.cloud/announcements/client-authentication-eku-support-removed-from-genesys-cloud-certificate/

Note Genesys BYOC Cloud uses subject name validation to ensure that the remote endpoint identifies itself as the expected target. If a server certificate does not contain the name to which the client is connected as either the common name or the subject alternate name, the connection is refused.

Below Table 1 is for reference. Modify the configuration according to the certificates in your environment.

Config Parameter	SBC Certificate (BYOC Cloud)	DigiCert High Assurance EV Root CA	DigiCert Global Root G2	DigiCert Global Root G3
Name	SBCCert	DigiCert High Assurance EV Root CA	DigiCert Global Root G2	DigiCert Global Root G3
Common Name	solutionslab.cgbubedford.com	DigiCert High Assurance EV Root CA	DigiCert Global Root G2	DigiCert Global Root G3
Key Size	2048	2048	2048	2048
Key-Usage-List	digitalSignature keyEncipherment	digitalSignature keyEncipherment	digitalSignature keyEncipherment	digitalSignature keyEncipherment
Extended Key Usage List	serverAuth	serverAuth	serverAuth	serverAuth
Key algor	rsa	rsa	rsa	rsa
Digest-algor	Sha256	Sha256	Sha256	Sha256

6.8.2.2 End Entity Certificate

The SBC's end entity certificate is what is presented to BYOC Cloud signed by your CA authority, in this example we are using Digicert as our signing authority.

Here in this setup,We wil create two end entity certificates for BYOC Cloud.

- Common name: (**solutionslab.cgbubedford.com**) for BYOC Cloud

Step 1 Configure SBC Certificate Record

To Configure the certificate record:

- Click Add, and configure the SBC certificate as shown below:



Step 2 – Generating a certificate signing request

Please note – certificate signing request is only required to be executed for SBC Certificate – not for the root/intermediate certificates.

- Select the certificate and generate certificate on clicking the "Generate" command.
- The Step must be performed for SBCBYOC CloudCert.

- Please copy/paste the text that is printed on the screen as shown below and upload to your CA server for signature.





- copy/paste the text that gets printed on the screen as shown above and upload to your CA server for signature.
- Also note, at this point, **a save and activate is required** before you can import the certificates to each certificate record created above.

Step 3 Import Certificates to the SBC

Once certificate signing request have been completed – import the signed certificate to the SBC.

Please note – all certificates including root and intermediate certificates are required to be imported to the SBC. Once all certificates have been imported, issue **save/activate** from the WebGUI



6.8.2.3 Import CA Certificate

Repeat the steps provided Step 3 to import all the root and intermediate CA certificates into the SBC as mentioned in Table 1.

At this stage, all the required certificates SBC certificates have been imported to the SBC

6.9 TLS-Profile

A TLS profile configuration on the SBC allows specific certificates to be assigned.

Navigate to security-> TLS-profile config element and configure the tls-profile as shown below

ACLI Path: config t->security->tls-profile

6.9.1 TLS-Profile - Genesys BYOC Cloud

Genesys Cloud BYOC only supports endpoints using the TLS version 1.2 protocol.

Supported TLS ciphers include:

Genesys Cloud supports below TLS ciphers-

- TLS_RSA_WITH_AES_256_CBC_SHA
- TLS_RSA_WITH_AES_128_GCM_SHA256
- TLS_RSA_WITH_AES_256_GCM_SHA384
- TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA*
- TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256*
- TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384*

On March 24, 2025, Genesys announced that in a future release, Genesys Cloud will no longer support the following BYOC Cloud TLS ciphers.

- TLS_RSA_WITH_AES_256_CBC_SHA256
- TLS_ECDHE_RSA_WITH_AES_256_CBC_SHA384

Between Oracle SBC and Genesys BYOC Cloud BYOC we have following common ciphers-

- TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256
- TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384

TLS-only listeners are available on host port 5061.



6.9.2 TLS-Profile- Microsoft Teams

TLS profile configuration on the SBC for Microsoft Teams allows for specific certificates to be assigned.

GUI Path: security/tls-profile

ACLI Path: config t→security→tls-profile

- Click Add, use the example below to configure



- Select OK at the bottom

6.10 Media Security

This section outlines how to configure support for media security between the OCSBC and Microsoft Teams Direct Routing.

6.10.1 SDES-Profile

This is the first element to be configured for media security, where the algorithm and the crypto's to be used are configured. The only crypto-suite option supported by Microsoft is AES_CM_128_HMAC_SHA1_80 and must be included in the crypto list

In the SBC's GUI, on the bottom left, you will need to enable the switch "Show All" to access the media security configuration elements.

GUI Path: security/media-security/sdes-profile

ACLI Path: config t→security→media-security→sdes-profile

- Click Add, and use the example below to configure



Please note, if you have media bypass enabled in your environment, the lifetime value of 31 is required for Teams clients to decrypt SRTP packets sent by the Oracle SBC.

- Select OK at the bottom

6.10.2 Media Security Policy

Media-sec-policy instructs the SBC how to handle the SDP received/sent under a realm (RTP, SRTP or any) and, if SRTP needs to be used, the sdes-profile that needs to be used

GUI Path: security/media-security/media-sec-policy

ACLI Path: config t→security→media-security→media-sec-policy

- Click Add, use the examples below to configure





- Select OK at the bottom of each when finished.

Note- Both Microsoft Teams and Genesys BYOC Cloud in this setup require TLS SRTP to work.You can re-use the same Sdes Profile and Media Sec Policy for Genesys BYOC Clous.

If any of your network component require RTP, another Media Sec policy as show below and named **RTP** ,to convert srtp to rtp can be created and applied to the appropriate realm as needed.

6.11 Configure SIP Interfaces

Navigate to sip-interface under session-router and configure the sip-interface as shown below.
Please configure the below settings under the sip-interface.

Please Configure sip-interface for the BYOC Cloud as below-

- Tls-profile needs to match the name of the tls-profile previously created
- Set allow-anonymous to agents-only to ensure traffic to this sip-interface only comes from the Session agents added to the SBC.

6.11.1 Sip-Interface for Microsoft Teams



6.11.2 Sip-interface for Genesys BYOC Cloud



Once sip-interface is configured – the SBC is ready to accept traffic on the allocated IP address.

6.12. Configure session-agent

Session-agents are config elements, which are trusted agents who can send/receive traffic from the SBC with direct access to trusted data path. Session-agents are config elements which are trusted agents who can send/receive traffic from the SBC with direct access to trusted data path.

Navigate to session-router->Session-Agent and **Configure the session-agents for the Genesys Pure Cloud**

- Host name to “byoc-voxai.byoc.mypurecloud.com”
- port to 5061
- realm-id – needs to match the realm created for the Genesys Pure Cloud
- transport set to “staticTLS”
- ping-method – send OPTIONS message to Microsoft to check health
- ping-interval to 30 secs



Configure the session-agent for Teams with the following parameters.
Go to session-router->Session-Agent.

- hostname to “sip.pstnhub.microsoft.com”
- port 5061
- realm-id – needs to match the realm created for Teams
- transport set to “StaticTLS”
- refer-call-transfer set to enabled
- ping-method – send OPTIONS message to Microsoft to check health
- ping-interval to 30 secs





Follow above steps to create 2 more sessions for:

- sip2.pstnhub.microsoft.com
- sip3.pstnhub.microsoft.com

6.13. Configure session-agent group

A session agent group allows the SBC to create a load balancing model.
Go to Session-Router->Session-Group. Please configure the following group for Teams Session Agents



6.14. Configure local-policy

Local policy config allows the SBC to route calls from one end of the network to the other based on routing criteria. To configure local-policy, Navigate to Session-Router->local-policy.

Please note that in the below example calls are routed to Twilio Elastic SIP Trunk. Here Twilio Elastic SIP Trunk is the BYOC Carrier. The call flow in the setup is as below –

Inbound calls from BYOC Cloud to Microsoft Teams –

Genesys BYOC Cloud → Oracle SBC → Carrier Trunk (Twilio) → Oracle SBC SBC → MS Teams

Inbound calls from Microsoft Teams to BYOC Cloud -

MS Teams→ Oracle SBC → Carrier Trunk (Twilio) → Oracle SBC SBC → Genesys BYOC Cloud

We have multiple application Notes available on the Oracle Technet Page to configure the Oracle SBC with different PBXs and Twilio Elastic SIP Trunk.

Below is the Link to Oracle Technet Page
https://www.oracle.com/technical-resources/documentation/acme-packet.html
Oracle SBC interworking with Genesys BYOC Cloud and Twilio SIP Trunk Application Note can be found here –

https://www.oracle.com/a/otn/docs/oracle-sbc-with-genesys-pure-cloud-and-twillio-sip-trunk.pdf

Following **local-policy routes the calls from the Genesys BYOC Cloud** to Carrier and then the calls are routed from Carrier to Microsoft Teams.





Following **local-policy routes the calls from the Microsoft Teams** to Carrier and then the calls are routed from Carrier to Genesys BYOC Cloud.





6.15. Configure steering-pool

Steering-pool config allows configuration to assign IP address(s), ports & a realm.

BYOC Cloud Steering pool.



Microsoft Teams Steering Pool



6.16. Configure additional Parameters

To simplify the ORACLE SBC sip manipulation, from GA Release SCZ830m1p7 contains three additional SBC configuration parameters which are not found in prior releases.

The purpose of these three parameters is to replace the majority of the sip manipulation rules required to be configured in the ORACLE SBC to properly interface with Microsoft Teams Direct Routing.

The first two parameters are found under the **realm-config** and would be enabled in realms facing Microsoft Teams.

They are **Teams FQDN in URI** and **SDP inactive only**.
The detailed description is given below for each config parameter.

Teams FQDN in URI:

When enabled, this parameter takes the FQDN configured under hostname of the network interface and inserts that into the Contact and FROM headers of Invites generated by the SBC towards Teams. This also adds a new “X-MS-SBC” Header to both Invite and OPTIONS Requests, which takes the place of the User-Agent header currently being added via Sip Manipulation. Lastly, SBC will add a Contact Header to outgoing SIP Options Pings, also containing the FQDN of the SBC listed under the hostname field of the network interface, and with the Contact Header added to OPTION Requests generated by the SBC, Record Route is no longer required.

SDP inactive only:

When enabled on Teams facing realm(s), this will modify the following SDP attributes in both requests and responses to and from Microsoft Teams

Message Type	Match Value	New Value
request	inactive	sendonly
reply	inactive	recvonly
request	sendonly	inactive
reply	recvonly	inactive





The third parameter is found under the **Session agent** configuration element and will be enabled on all session agents configured for Microsoft Teams and Genesys BYOC Cloud .Below is an example of the parameter **Ping response** enabled on BYOC Cloud Session-Agent. Similarly, the parameter should be enabled for other Microsoft Teams Session-Agents.



6.17. Configure Media Profile and Codec Policy

The Oracle Session Border Controller (SBC) uses codec policies to describe how to manipulate SDP messages as they cross the SBC. The SBC bases its decision to transcode a call on codec policy configuration and the SDP. Each codec policy specifies a set of rules to be used for determining what codecs are retained, removed, and how they are ordered within SDP.

Note: this is an optional config – configure codec policy only if deemed required

SILK & CN offered by Microsoft teams are using a payload type which is different than usual.
Configure the media-profile as shown below,
Go to Session-Router->Media-profile



Configure media profiles similarly, for silk codec also as given below.

Parameters	SILK-1	SILK-2
Subname	narrowband	wideband
Payload-Type	103	104
Clock-rate	8000	16000

After creating media profile, create codec-policy, addCN, to add comfort noise towards Teams.
Go to media manager ---- codec policy



Apply this codec policy on the Teams realm

6.18. Configure ice profile

SBC supports ICE-Lite. This configuration is only required to support Teams media-bypass.
Configure the following ice profile and apply it on the realm towards Teams.
Go to media-manager->ice-profile. **Note: This config is required only for Media bypass model and its not needed for Non media bypass model.**





6.19 Configure RTCP Policy and RTCP Mux

The RTCP policy needs to be configured in order to generate RTCP reports towards Teams
Go to Media-manager->rtcp-policy to configure rtcp-policy.



Apply this RTCP policy on the Teams realm. Enable rtcp-mux also in the realm.
With this, SBC configuration is complete

6.20 Access Control

To enhance the security of your Oracle Session Border Controller, we recommend configuration access controls to limit traffic to only trusted IP addresses on all public facing interfaces

GUI Path: session-router/access-control

Please use the example below to configure access controls in your environment for both BYOC Cloud IP's, as well as SIP Trunk IP's (if applicable).

The IP for NAM region are -

IP Addresses	Load Balancer DNS Names
52.203.12.137	lb01.voice.use1.pure.cloud
54.82.241.192	lb02.voice.use1.pure.cloud
54.82.241.68	lb03.voice.use1.pure.cloud
54.82.188.43	lb04.voice.use1.pure.cloud

Complete IP details can be found below-
https://help.genesys.cloud/articles/byoc-cloud-public-sip-ip-addresses/

Configure access-control for each IP BYOC Cloud IP Address or Subnet as shown in the below example.



Similarly create ACL entries for each Microsoft Teams IP Addresses as shown in the below example. Microsoft Teams has two subnets, 52.112.0.0/14 and 52.120.0.0/14 that must be allowed to send traffic to the SBC. Both must be configured as an access control on the Oracle SBC and associated with the realm facing Teams. Use this example to create ACL's for all MSFT Teams subnets. This example can be followed for any of the public facing interfaces, ie…SipTrunk, etc…

GUI Path: session-router/access-control
ACLI Path: config t/session-router/access-control

Use this example to create ACL's for both MSFT Teams subnets, 52.112.0.0/14 and 52.120.0.0/14.



Notice the trust level on this ACL is set to high. When the trust level on an ACL is set to the same value of as the access control trust level of its associated realm, this create an implicit deny, so only traffic from IP addresses configured as ACL's with the same trust level will be allowed to send traffic to the SBC. For more information about trust level on ACL's and Realms, please see the SBC Security Guide, Page 3-10.

7. Configuring the Oracle SBC through Config Assistant

When you first log on to the Oracle SBC, the system requires you to set the configuration parameters necessary for basic operation. To help you set the initial configuration with minimal effort, the SBC provides the Configuration Assistant.
The Configuration Assistant, which you can run from the Web GUI or the Acme Command Line Interface (ACLI), asks you questions and uses your answers to set parameters for managing and securing call traffic. You can use the Configuration Assistant for the initial set up to make to the basic configuration. Please check "Configuration Assistant Operations" in the Web GUI User Guide and "Configuration Assistant Workflow and Checklist" in the ACLI Configuration Guide

Please note, applying a configuration to the SBC via the Configuration Assistant will overwrite any existing configuration currently applied to the SBC. **We highly recommend this only be used for initial setup of the SBC. This feature is not recommended to be used to make changes to existing configurations.**

Configuration package is available starting in release nnSCZ840p7 and nnSCZ900p2.

Section Overview and Requirements

This section describes how to use our Configuration Assistant feature as a quick and simple way to configure the Oracle SBC for integration with Genesys BYOC Cloud. We will choose a Generic SIP Trunk on the other Side for Carrier Connectivity. We also have configuration Assistant for Microsoft Teams related for Microsoft Teams related configuration. Please follow the latest Microsoft Teams Application Note to get instructions on configuring Microsoft Teams via Configuration Assistant Template.

The Application notes can be found at - https://www.oracle.com/technical-resources/documentation/acme-packet.html

The pre-requisites are given below.

- SBC running release SCZ840p7 or later which will have this template package by default added to the SBC code.
- TLS certificate for the SBC preferably in PKCS format, or access to BYOC Cloud supported CA to sign certificate once CSR is generated by the SBC.

The following outline assumes you have established initial access to the SBC via console and completed the following steps:

- Configured boot parameters for management access
- Setup Product
- Set Entitlements
- Configured HTTP-Server to establish access to SBC GUI

Initial GUI Access

The Oracle SBC WebGui can be accessed by entering the following in your web browser.
http(s)://<SBC Management IP>.

The username and password are the same as that of the CLI.

If there is no configuration on the SBC, the configuration assistant will show immediately upon login to the SBC GUI as shown below

BYOC Cloud Configuration Assistant

For a new SBC deployment, once access to the GUI is configured, you will see the following when logging in for the first time:



Under PBX template, we'll select BYOC Cloud template. This brings up a list of available sip trunk templates.



Select a sip trunk template and click Next at the top to access the Notes page. Pay close attention to the information here, as this is a list of warnings, pre-requisites, and recommendations:



Clicking “Next” on the Notes page triggers the configuration assistant to do a system check. This ensures that all of the system requirements for the platform and sip trunk you have selected have been met before proceeding to configuration pages. If they have not been met, you will be greeted by a page providing the opportunity to setup entitlements, add license keys, etc. before moving on to the configuration.

Once all requirements for your selected templates have been satisfied, you can proceed to the configuration pages.

Page 1- BYOC Cloud Network

Page 1 of the template is where you will configure the network information to connect to BYOC Cloud Network.

Next to each field is a help icon. If you hover over the icon, you will be provided with a description or definition of each filed. Also, pay close attention to which fields are listed as “required”.



Page 2 - Import DigiCert Trusted CA Certificate for BYOC Cloud

Page 2 of this template is where the SBC will import the **DigiCert High Assurance EV Root Cert CA** certificate, which BYOC Cloud uses to sign the certificates it presents to the SBC during the TLS handshake.

Importing the BYOC Cloud Root CA certs is enabled by default.



Page 3 - SBC Certificates for BYOC Cloud side

By default, the SBC is set to import a certificate in PKCS12 format. This is the simplest and recommended way to add a certificate to the Oracle SBC. Using this method, you will add the SBC's hostname under "FQDN or

Common Name" field, upload a certificate signed from one of the BYOC Cloud Supported CA Vendors, and enter the certificates password.



Certificate Signing Request (CSR)

The alternative to importing a PKCS12 certificate to the SBC is to configure a certificate and generate a certificate signing request that you will have signed by a BYOC Cloud supported CA. Same as PKCS12, you will enter the SBC's hostname under "FQDN or Common Name" and "Country" field (required) and answer the remaining question presented on this page (optional).



Page 4 is where you will be able to configure transcoding between the SBC and BYOC Cloud.

Once transcoding features is set to “yes”, you will then have an option to select additional media codecs you want included in offers/answers toward BYOC Cloud. If you select yes to either question regarding media codecs, you will be presented with a required drop down.

You can select as many codecs as possible from the list presented.



Page 5 – PSTN Sip Trunk Network

Page 5 of the template is where you will configure the network information to connect to PSTN SIP trunk Network. Please fill the required fields and Press Next.



Page 6 – PSTN Session Agent

Page 6 of the template is where you will configure the PSTN Session Agent details where you will enter the next hop IP address and port for sip signaling to and from your PSTN SIP trunk.



Please fill the required fields and click Next.

Page 7 - PSTN side Transcoding

Page 7 is where you will be able to configure transcoding between the SBC and PSTN Trunk.

Once transcoding features is set to “yes”, you will then have an option to select additional media codecs you want included in offers/answers towards PSTN trunk. If you select yes to either question regarding media codecs, you will be presented with a required drop down. You can select as many codecs from the list presented.



Page 8 – Additional Configuration

Page 8 of this template is where you perform additional optional configuration. Hover over to the **?** to know more about each Option.



Review

At the end of the template, you will notice in the top right, a "*Review*" tab. If all 8 pages presented across the top are showing green, indicting there are no errors with the information entered, click on the "Review" tab.



The screen looks like below after clicking the Review Tab. The left side of the review page contains all of the entries added on each page and allows for editing each page individually if necessary.

The right side displays the entire configuration created and when applicable, will also have a CSR tab that contains a certificate that can be signed by a CA authority.



On the left side of the review contains the entries for each page. Each page has an "*Edit*" tab that can be used to make changes to the information entered on that specific page without having to go through the entire template again.

On the right side of the review page, under the "*Configuration*" tab is the ACLI output from the SBC. This is the complete configuration of the SBC based on the information entered throughout the template. Also, on the right side of the review page you may see another tab, "*CSR*".

On Page 3 of the template, if you chose CSR from the drop-down menu instead of PKCS, the SBC configures a certificate record and generates a certificate signing request for you.



Click the copy button under the CSR and paste the output into a text file. Next, provide the txt file to your CA for signature. Once the certificate is signed by the CA, you will need to import that certificate into the SBC manually, either via ACLI or through the GUI.

Note: if you chose to import a certificate in PKCS12 format on page 3, the CSR tab will not be present under review.

Download and/or Apply

The template provides you with the ability to "Download" the config by clicking the "*Download*" tab on the top right. Next, click the "*Apply*" button on the top right, and you will see the following pop-up box appear.

Now you can click "*Confirm*" to confirm you want to apply the configuration to the SBC. The SBC will reboot. When it comes back up, the SBC will have a basic configuration in place for BYOC Cloud Phone with Generic PSTN Sip Trunk.

Configuration Assistant Access

Upon initial login, if the Configuration Assistant Template does not immediately appear on the screen, you can access by clicking on the "*SYSTEM*" tab, top right of your screen. After that, click on the "*Configuration Assistant*" tab, top left. This allows end users to access the Configuration Assistance at any time through the SBC GUI.

8. Test Plan Executed

We have executed the following test plan to validate the interworking between Genesys BYOC Cloud and Twilio SIP Trunk via Oracle SBC.

Test	Description	Pass	Fail
Outbound Local	Place an outbound call to a local number	YES	
Outbound Long-Distance	Place an outbound call to a long-distance number	YES	
Outbound International	Place an outbound call to an international number (if applicable)	YES	
Outbound Toll-Free	Place an outbound call to a toll-free number	YES	
Inbound	Place an inbound call to the range of numbers pointed to your system	YES	
Hold	Place an outbound call to any number, place call on hold for 1 minute, take call off hold	YES	
Transfer Call	Place a call, transfer the call, ensure both parties connect successfully	YES	
Call Forward	Enable call forward on phone, place call to phone, confirm call forwards successfully	YES	
Conference	Create a conference call with 3 or more people on the same call	YES	
DTMF	Call 1-800-COMCAST, confirm DTMF is received	YES	
Outbound Duration	Place outbound call, keep it connected for 10+ minutes	YES	
Inbound Duration	Place inbound call, keep it connected for 10+ minutes	YES	

Oracle Corporation, World Headquarters
500 Oracle Parkway
Redwood Shores, CA 94065, USA

Worldwide Inquiries
Phone: +1.650.506.7000
Fax: +1.650.506.7200

ORACLE

CONNECT WITH US

blogs.oracle.com/oracle

facebook.com/Oracle/

twitter.com/Oracle

oracle.com

Integrated Cloud Applications & Platform Services